

Leaflet: Sampling of TOC-Samples

In order to ensure a swift and error-free TOC-determination, we kindly ask you to pay attention to the following details:

General Information

- Please wear gloves.
- In case of direct sampling from tap: ensure that enough water has passed through the tap for rinsing before sampling.
- TOC-tubes must not be in contact with alcoholic solutions and must not be autoclaved.
- Please use labels that allow easy removal.
- Recommendation: Please send 2 TOC tubes per sample so that optionally a re-measurement can be performed.

Pre-cleaning of TOC Tubes

- Fill TOC tubes with sample.
- (if sample availability is limited, use purified water)
- Screw lid with septum on vessel.
- Shake tube thoroughly.
- Empty tube.
- Repeat this three times.

Final Filling and Packaging of Sample Tubes

- After pre-cleaning, fill tube with sample (at least 20 mL).
- Screw lid tightly on tube.
- Preferably put all TOC tubes in a plastic bag that can be closed and send them shock-protected to UFAG LABORATORIEN AG.

In case that you decide to use your own or larger sample tubes, please proceed in analogy.

Do you have further questions?

Contact us! Our customer service department will be happy to advise you.

Thank you in advance for your order and for putting your confidence in us.

Kind Regards

UFAG LABORATORIEN AG

Note:

This leaflet is a non-binding recommendation from UFAG Laboratorien AG. The method can of course be adapted to suit your own requirements and processes.